

#### **Open Source Data Processing With**

# OpenDroneMap

Corey Snipes
Twomile Heavy Industries, Inc.
corey@twomile.com

UCANR DroneCamp - June 24, 2020

#### Hands-On Exercises

These slides are a companion to the "Open Source Data Processing With ODM" session at DroneCamp 2020. They walk through the hands-on exercises. If you would like a paper copy of the exercises to use as we go, print these and have them on hand for the session.

- Part A Processing
- Part B Working With Outputs




# HANDS-ON WITH ODM

Part A - Start Processing

### Download Sample Data


https://github.com/coreysnipes/drone\_dataset\_brighton\_beach




# Unzip Files




# Open WebODM Lightning




# Add Images




# Add Images




# Set Configuration




# Set Configuration



# Set Configuration




### **Start Processing**



# **Processing Status**



### Running





# HANDS-ON WITH ODM

Part B – Working with ODM Outputs


### WebODM vs. WebODM Lightning

- WebODM
  - Install for free
  - Process locally for free
- WebODM Lightning




- Commercial service
- Install for free
- Process in the cloud (\$)

### Still Running?




#### Finished

■ Today, Speed > Quality




### Exercises – 2D Orthophoto




# #1 - Orthophoto - Navigate

- A. Click+hold = move map
- B. Scroll wheel = zoom in/out
- C. Map controls +/-= zoom
- D. Map control square = full screen
- E. Top buttons:
  - A. Ortho
  - B. Plant Health
  - C. Surface Model
  - D. Terrain Model



### #2 - Orthophoto - Measure

- A. Click ruler (4<sup>th</sup> on right)
- B. Create new measurement
- C. Click 2 points on map
- D. Click "Finish measurement"
- E. View calculations in white balloon
- F. Close balloon with "x"
- G. Click ruler again, new measurement
- H. Click 4 points on map to make a box, click "Finish"
- I. View calculations
- J. Click "Delete" to remove it




#### #3 - Plant Health

- A. 2<sup>nd</sup> Top Button: Plant Health
- B. Note color differences in different grassy areas
- C. Click top right "layers" icon
- D. View "Algorithm" options
- E. View "Color" options
- F. Drag min/max bars
- G. Export GeoTIFF




### #4 – Surface Model (DSM)

- A. 3rd Top Button: Surface Model
- B. Wait for calc/load
- C. Note color varies by altitude
- D. Click top right "layers" icon
- E. View "Color" options
- F. Drag min/max bars
- G. Wait for refresh
- H. Export GeoTIFF




### #5 – Terrain Model (DTM)

- A. 4<sup>th</sup> Top Button: Terrain Model
- B. Wait for calc/load
- C. Note color varies by altitude
- D. Click top right "layers" icon
- E. View "Color" options
- F. Drag min/max bars
- G. Wait for refresh
- H. Export GeoTIFF




#### Exercises - 3D Model




### #6 – 3D Model - Navigate

- A. Left click+drag = rotate model
- B. Right click+drag = move model
- C. Scroll wheel = zoom in/out
- D. Top left (3 bars) button = collapse tools
- E. Top left (map) button = show model location
- F. Tools
  - A. Measure
  - B. Navigation
- G. Appearance
- H. Scene




### #7 – 3D Model – Measure (Linear)

- A. Adjust the model so you can see
- B. Click 3<sup>rd</sup> Measurement tool (angled line)
- C. LEFT click 2 points in a grassy area on the map
- D. Now RIGHT click the last point to finish
- E. View measured distance (m)
- F. Click red "X" in measurement tools, to delete



### #8 - 3D Model - Measure (Area)

- A. Adjust the model so you can see
- B. Click top right Measurement tool (red box)
- C. LEFT click 4 points in a grassy area on the map
- D. Now RIGHT click the last point to finish
- E. View measured distances (white)
- F. View measured area (green)




#### #9 - View Textured Model

- A. Find "Textured Model" near the top of the tool menu
- B. Click to expand, then click "Show Model"
- C. Wait a few seconds
- D. View how the scene becomes more detailed, holes are filled
- E. Uncheck and check the box to turn off, and on
- F. Move the model around to view other parts
- G. Edges of model = lots of error Interior of model = better precision




#### #10 - View Cameras


- A. Find "Cameras" near the top of the tool menu
- B. Click to expand, then click "Show Cameras"
- C. Zoom out (scroll) until you see the blue squares floating above the scene
- D. Note positions, angles of cameras
- E. Click one camera to see the photo from that position




#### Exercises - Download



### #11 – Download Orthophoto





# **END**

Hands-On Exercises Open Source Data Processing with ODM UCANR DroneCamp - June 24, 2020